

Replacement Sheet

OCTETS

1	TLV_type_=Local_Status	
1	Local_Status_Length=0x14	
2	Local_State	~201
2	Local_OAM_Configuration	
2	Local_OAMPDU_Configuration	
2	Local_Loopback_Configuration	
6	Local_Extension	
0	Local_placeholder	
1	Local_Allocated_channel	~203
1	Local_Topology	~205
6	Reserved	
1	TLV_type=Far_End_Status	
1	Far_End_Status_Length=0x14	
2	Far_End_State	~207
2	Far_End_OAM_Configuration	
2	Far_End_OAMPDU_Configuration	
2	Far_End_Loopback_Configuration	
6	Far_End_Extension	
0	far_end_placeholder	
1	Far_Allocated_channel	~209
1	Far_Topology	~211
6	Reserved	



FIG.6